



HBM Variants Generation based on
the occupant's BMI

BETA CAE Systems S.A

HBM Variants Generation Tool

Dimitris Zouzias

BETA CAE Systems CS

Thanasis

Fokilidis

BETA CAE Systems CS

Lambros Rorris

BETA CAE Systems AG

Thanasis Lioras


BETA CAE Systems SA

Outline

- **Problem Statement**
- **Proposed Solution**
- **Key Features**
- **Main Advantages**
 - **Wide Range of BMIs**
 - **Profound Mesh Quality**
- **Outputs & Compatibility with Analysis Tools**
- **Case Study**


Problem Statement

- State of the art models represent only a small sample of the population.



Problem Statement

- Occupant injury patterns and kinematics are linked to the subject's BMI.*
- Current variant generation processes:
 - Are solely based on morphing techniques
->Mesh of poor quality.
 - Do not take into account the variation of abdominal organs' volume vs subject's BMI.



Outline

- **Problem Statement**
- **Proposed Solution**
- **Key Features**
- **Main Advantages**
 - **Wide Range of BMIs**
 - **Profound Mesh Quality**
- **Outputs & Compatibility with Analysis Tools**
- **Case Study**

Proposed Solution


ANSA HBM Variant Generation Tool

ANSA HBM Variant Generation Tool

- Combination of Meshing and Morphing Tools
- Automatic generation of HBM Variants in 25 mins
 - > BMI as sole input.


Key Features

- Wide range of BMIs (26 to 40)
- Enhanced creation of subcutaneous fat.
- Abdominal organs morphing.




ANSA HBM Variant Generation Tool

Key Features – Enhanced Creation of Subcutaneous Fat



ANSA HBM Variant Generation Tool

Key Features – Abdominal Organs Morphing



- Liver
- Pancreas
- Gallbladder
- Kidneys
- Stomach

Outline


- **Problem Statement**
- **Proposed Solution**
- **Key Features**
- **Main Advantages**
 - **Wide Range of BMIs**
 - **Profound Mesh Quality**
- **Outputs & Compatibility with Analysis Tools**
- **Case Study**

ANSA HBM Variant Generation Tool

Main Advantages

- Developed for GHBMC model but can be extended to any HBM.
- Requires the simple addition of an ANSA metadata file.
- Creation of a new variant within 25 mins.
 - No prior knowledge of morphing or meshing is required.
 - Profound meshing quality.


ANSA HBM Variant Generation Tool Main Advantages – Profound Mesh Quality



- The number of rows is adjusted to the model's BMI.
- Smooth element density.

ANSA HBM Variant Generation Tool

Main Advantages – Profound Mesh Quality




Outline

- **Problem Statement**
- **Proposed Solution**
- **Key Features**
- **Main Advantages**
 - **Wide Range of BMIs**
 - **Profound Mesh Quality**
- **Outputs & Compatibility with Current Analysis Tools**
- **Case Study**

ANSA HBM Variant Generation Tool

Outputs & Compatibility with Current Analysis Tools




BMI = 40




BMI = 36




BMI = 35



BMI = 31



BMI = 29



BMI = 26

ANSA HBM Variant Generation Tool

Outputs & Compatibility with Current Analysis Tools

- All new elements organised in a new *INCLUDE
- Direct output of the *NODE keywords
- Can be coupled with all existing tools
 - Seatbelt Tool
 - HBM Articulation
 - Seat Positioning
 - Mesh Check / Fix Tools

ANSA HBM Variant Generation Tool

Outputs & Compatibility with Current Analysis Tools





- HBM Variants tool
- HBM Articulation tool
- Seatbelt tool

Outline


- **Problem Statement**
- **Proposed Solution**
- **Key Features**
- **Main Advantages**
 - **Wide Range of BMIs**
 - **Profound Mesh Quality**
- **Outputs & Compatibility with Current Analysis Tools**
- **Case Study**

Case Study



- Kinematics w/o IP
- Loadings with IP


Case Study




■ Obese

■ Reference

Case Study






Reference






Obese

Tibia -
Fibula




Femur



Reference

Obese



Stay connected